

Removal of On-Board Battery from LX-800 Processor



Revision: 3.0

Revision Date: 9/8/2025 3:22 PM

Doc #: 480001

Page 1/5

1.0 Purpose


Instructions for the removal of the on-board batteries. To be used for new products and field removal of batteries to mitigate battery case failure losses.

2.0 Scope

This procedure applies to LX-800 processors with Quad Serial boards carrying a 402059 CMOS battery.

3.0 Eligibility

- LX-800 with Quad Serial Board
- Comet Part # 402059 Battery Installed



4.0 Required Equipment

- Small Diagonal Cutters
- 7/32 Nut Driver or Wrench

Comet Electronics Proprietary Information

This document is the property of Comet Electronics, LLC. It may be used by recipient only for the purpose for which it was transmitted and will be returned upon request or when no longer needed by recipient. It may not be copied or communicated without the written consent of Comet Electronics. In addition, this document could contain technical data, the export of which is restricted by the U.S. Arms Export Control Act (AECA) (title 22, U.S.C. Sec 2751, et seq.) Or the Export Administration Act of 1979, as amended (title 50, U.S.C., app. 2401, et seq.).

Removal of On-Board Battery from LX-800 Processor



Revision: 3.0

Revision Date: 9/8/2025 3:22 PM

Doc #: 480001


Page 2/5

- Necessary PPE (Safety glasses, nitrile gloves)

5.0 Procedure

1. Disconnect 402059 Battery

- a. Pull the plug of the 402059 battery off the Quad Serial



Board.

2. Remove Quad Serial Board

- a. Gently pull the Quad Serial Board Loose from the LX-800.
- b. Remove 4 nuts from the board.

Comet Electronics Proprietary Information

This document is the property of Comet Electronics, LLC. It may be used by recipient only for the purpose for which it was transmitted and will be returned upon request or when no longer needed by recipient. It may not be copied or communicated without the written consent of Comet Electronics. In addition, this document could contain technical data, the export of which is restricted by the U.S. Arms Export Control Act (AECA) (title 22, U.S.C. Sec 2751, et seq.) Or the Export Administration Act of 1979, as amended (title 50, U.S.C., app. 2401, et seq.).

Removal of On-Board Battery from LX-800 Processor




Revision: 3.0

Revision Date: 9/8/2025 3:22 PM

Doc #: 480001

Page 3/5



Comet Electronics Proprietary Information

This document is the property of Comet Electronics, LLC. It may be used by recipient only for the purpose for which it was transmitted and will be returned upon request or when no longer needed by recipient. It may not be copied or communicated without the written consent of Comet Electronics. In addition, this document could contain technical data, the export of which is restricted by the U.S. Arms Export Control Act (AECA) (title 22, U.S.C. Sec 2751, et seq.) Or the Export Administration Act of 1979, as amended (title 50, U.S.C., app. 2401, et seq.).

Removal of On-Board Battery from LX-800 Processor



Revision: 3.0

Revision Date: 9/8/2025 3:22 PM

Doc #: 480001

Page 4/5

ATTENTION:

- Do not short across the leads of any battery.
- If the battery case is damaged, do not perform this procedure.
- Once the battery is removed, handle the battery so that the exposed leads will not short.

NOTE:

- The battery is glued to a chip on the board underneath. Use caution when applying force to remove the battery.
- Do not pry up on the battery.


3. Remove Battery

a. Identify the battery:

- a. Approx $\frac{3}{4}$ "x $\frac{1}{2}$ "x $\frac{1}{4}$ "
- b. Near STD Bus
- c. Silver or Yellow

b. Using diagonal cutters, Clip 2 leads, as shown.

c. Firmly rotate the battery back and forth until the battery comes loose of the adhesive.



Comet Electronics Proprietary Information

This document is the property of Comet Electronics, LLC. It may be used by recipient only for the purpose for which it was transmitted and will be returned upon request or when no longer needed by recipient. It may not be copied or communicated without the written consent of Comet Electronics. In addition, this document could contain technical data, the export of which is restricted by the U.S. Arms Export Control Act (AECA) (title 22, U.S.C. Sec 2751, et seq.) Or the Export Administration Act of 1979, as amended (title 50, U.S.C., app. 2401, et seq.).

Removal of On-Board Battery from LX-800 Processor



Revision: 3.0


Revision Date: 9/8/2025 3:22 PM

Doc #: 480001

Page 5/5


4. Reassemble Quad Serial Board

- Align the Connecting standoffs of the Quad Serial Board with the LX-800 and gently reconnect the two boards.
- Replace the connecting Standoff nuts.



5. Reconnect the 402059 Battery

- Connect the plug of the 402059 battery to the Quad Serial



Board.

Comet Electronics Proprietary Information

This document is the property of Comet Electronics, LLC. It may be used by recipient only for the purpose for which it was transmitted and will be returned upon request or when no longer needed by recipient. It may not be copied or communicated without the written consent of Comet Electronics. In addition, this document could contain technical data, the export of which is restricted by the U.S. Arms Export Control Act (AECA) (title 22, U.S.C. Sec 2751, et seq.) Or the Export Administration Act of 1979, as amended (title 50, U.S.C., app. 2401, et seq.).

Removal of On-Board Battery from LX-800 Processor



Revision: 3.0


Revision Date: 9/8/2025 3:22 PM

Doc #: 480001

Page 6/5

6. Verify System Time and Date

- Install the LX-800 into a Comet APU and power the system on.
- Connect a Hyper Terminal Client to the APU and log in.
- The Date and Time will be displayed after selecting a session.
- If the Time and Date need to be adjusted, follow the instructions in the AEI Operations manual to set the



Date/Time using the T command.

7. Dispose of Removed Battery

- Follow best practices for recycling and or disposing of e-waste to dispose of removed battery.



Comet Electronics Proprietary Information

This document is the property of Comet Electronics, LLC. It may be used by recipient only for the purpose for which it was transmitted and will be returned upon request or when no longer needed by recipient. It may not be copied or communicated without the written consent of Comet Electronics. In addition, this document could contain technical data, the export of which is restricted by the U.S. Arms Export Control Act (AECA) (title 22, U.S.C. Sec 2751, et seq.) Or the Export Administration Act of 1979, as amended (title 50, U.S.C., app. 2401, et seq.).

Removal of On-Board Battery from LX-800 Processor



Revision: 3.0

Revision Date: 9/8/2025 3:22
PM

Doc #: 480001

Page 7/5

Comet Electronics Proprietary Information

This document is the property of Comet Electronics, LLC. It may be used by recipient only for the purpose for which it was transmitted and will be returned upon request or when no longer needed by recipient. It may not be copied or communicated without the written consent of Comet Electronics. In addition, this document could contain technical data, the export of which is restricted by the U.S. Arms Export Control Act (AECA) (title 22, U.S.C. Sec 2751, et seq.) Or the Export Administration Act of 1979, as amended (title 50, U.S.C., app. 2401, et seq.).